


# BOX-200



## 1、Input

For connection of bass guitars. Input-Hi for connecting a bass guitars equipped with passive pickups, Input-Lo for connecting a bass guitar equipped with active pickups. If both the Low and high inputs are used, their levels are both Low.

## 2、Gain

This control is used to set the level of gain present in the pre-amp.

## 3、Volume

Sets the overall listening level of the amplifier.

## 4、Compressor

Engages and disengages the on board compressor.

## 5、Enhance

Turning the control through to its maximum has the effect of boosting both the low and high-frequency content of the signal whilst not affecting the mid.

## 6、Bass

Adjusts the low-frequency level.

## 7、Mid EQ

Mid Level-Adjusts the mid-frequency level in the range set by the Mid Freq knob.

Mid Freq- Sets the mid-frequency range that the Mid Level knob adjusts.

## 8、Treble

Adjusts the high-frequency level.

## 9、Phone

Sockets for connections of external headphones connecting headphones automatically isolates internal speaker

## 10、DI Out

A line level output for connection To another amplifier of dest, etc.

## 11、Tuner Out

Socket for connecting external tuner

## 12、Power LED

The LED will be let when your amplifier is on.

## 13、Power Switch

Switches the amplifier on and off

## TECHNICAL SPECIFICATION

Power Output:	200W
Power Requirements:	230V 50HZ/110V 60HZ
Dimensions (H×W×D):	HEAD 220×600×210(mm) CABNIT 740×650×320(mm)
System Hum and Noise:	≥70dB
Input impedance:	>1MΩ
Speakers impedance:	8Ω (15" +horn)

## 1、輸入插孔(INPUT)

用于連接貝司，其中高增益輸入插口（INPUT-HI）用于接輸出電平較低的貝司（大部分貝司屬於此類型），低增益輸入插口（INPUT-LO）用于接輸出電平比較高的貝司，當2個插孔同時使用時，做低增益輸入插口使用。

## 2、增益調節(GAIN)

用于調節整機的前置放大。

## 3、音量調節(VOLUME)

用于調節整機音量。

## 4、壓縮開關(COMPRESOR)

啓動式關閉內設壓縮器。

## 5、提升(Enhance)

用于提升低音與高音，而同時不影響中音，用于產生一些特殊效果的音色。

## 6、低音調節(BASS)

用于調節低音區的提升/衰減量。

## 7、中頻幅度(MID Level)-用于調節中頻頻率(MID Freq)

所設定的中頻幅度。

中頻頻率(MID FRE)-用于設定中頻幅度(MID Level)

所調節的中頻頻率。

## 8、高音調節(TREBLE)

## 9、耳機輸出插口(PHONE)

用于連接耳機，這時機內揚聲器連接會斷開。用于調節高音區的提升/衰減量。

## 10、直接輸出插孔(DI OUT)

用于連接其它的錄音設備或者功率放大器。

## 11、調音輸出(TunEr Out)

用于連接外接調音器。

## 12、電源指示燈(POWER LED)

用于指示機器的工作狀態，紅燈表示本功放已開機。

## 13、電源開關(POWER SWITCH)

用于接通電源

## 主要技術指標:

輸出功率:	200W
電源:	AC220V 50HZ/AC110V 60HZ
外型尺寸(HXWXD):	箱頭 220×600×210(mm) 箱體 740×650×320(mm)
信噪比:	≥70dB
輸入阻抗:	>1MΩ
揚聲器阻抗:	8Ω (15" +horn)